#### Product Manual - Long Span III Roof Panels - Rake

RA01/AB, Panel Closure Detail at Rake

RA01/AD, Panel Closure Detail at Rake (Slopes Less Than 11/2:12)

RA02A/BO, Rake Detail

RA02/BA, Rake Detail

RA02/BD, Rake Detail

RA02/BO, Rake Detail

RA02FA/BO, Fixed Rake Detail

RA02F/BA. Fixed Rake Detail

RA02F/BD, Fixed Rake Detail

RA02F/BO, Fixed Rake Detail

RA03A/BA, Rake Cap Installation

RA03B/BA, Rake Cap Installation

RA03/BA, Universal Rake Cap Installation

RA04A/AA, Corner Cap Box Installation

RA04A/BA, Highside Corner Box

RA04W/AA, Corner Cap Box Installation

RA05/BA, Rake Detail

RA06/AA, Inside Corner Cap Installation

RA07A/BA, Cleated Rake/Peak Installation

RA07/BA, Rake/Peak Installation

RA14/AA, Ridge Flashing Endcap Installation

RA14A/AA, Roof to Wall Flashing Endcap Installation

RA30/BB, Roof to Wall Transition

RA32/BA, Ridge Expansion Detail at Roof to Wall Transition

RA62A/BO, Cleated Rake Detail

RA62/BB, Cleated Rake Detail

RA62/BD, Cleated Rake Detail

RA62/BO, Cleated Rake Detail

RA70/AA, Universal Rake Endcap Installation

RA70A/AA, Highside Eave Endcap, Without Corner Box

RA71/AA, Cleated Rake Endcap Installation

### PRODUCT MANUAL

LONG SPAN III ROOF PANELS

A NUCOR COMPANY


NOTES:

1 1/2:12 OR LESS

GREATER THAN 1 1/2:12

2. BEVEL CLOSURE

Panel Closure Detail at Rake Architectural III, Architectural "V" Rib or Long Span III Walls RA01/AB




Download the DWG file by clicking here.

### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Panel Closure Detail at Rake (Slopes Less Than 1 1/2:12) Shadow Panel Walls RA01/AD




Download the DWG file by clicking here.

#### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Rake Detail
Long Span III Roof / At Overhang or Canopy
RA02A/BO




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Rake Detail Long Span III Roof RA02/BA



Download the DWG file by clicking here.

To Section Index


Revised: 8/31/2018

#### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Rake Detail Long Span III Roof / Shadow Panel Walls RA02/BD




Download the DWG file by clicking here.

#### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Rake Detail Long Span III Roof / At Open Wall RA02/BO




Download the DWG file by clicking here.

#### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Fixed Rake Detail
Long Span III Roof / At Overhang or Canopy
RA02FA/BO




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Fixed Rake Detail Long Span III Roof RA02F/BA




Download the DWG file by clicking here.

### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Fixed Rake Detail Long Span III Roof / Shadow Panel Walls RA02F/BD




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Fixed Rake Detail Long Span III Roof / At Open Wall RA02F/BO




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Rake Cap Installation Long Span III (Expansion Ridge) RA03A/BA



Download the DWG file by clicking here.

To Section Index


Revised: 03-31-2020 (MR2020.03)



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Rake Cap Installation Long Span III (Vented Ridge) RA03B/BA




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Universal Rake Cap Installation Long Span III Roof w/ Die Formed Ridge RA03/BA



Download the DWG file by clicking here.

To Section Index


Revised: 2/7/2020

#### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Corner Cap Box Installation Typical All Roof Panels RA04A/AA



Download the DWG file by clicking here.

To Section Index


Issued: 12-29-17 (MR 2017.Q4)



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Highside Corner Box Long Span III Roof w/ Standard Rake RA04A/BA




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Corner Cap Box Installation Long Span III Roof (Universal Rake) RA04W/AA




Download the DWG file by clicking here.

### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Rake Detail
Expanded View of Rake Connection / Long Span III Roof
RA05/BA



Download the DWG file by clicking here.




LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Inside Corner Cap Installation

RA06/AA




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Cleated Rake/Peak Installation Long Span III w/Ridge Flashing RA07A/BA



Download the DWG file by clicking here.

To Section Index


Revised: 9/8/20

### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Rake/Peak Installation Long Span III Roof w/Die Formed Ridge RA07/BA



NOTES:

FIELD CUT, NOTCH AND BEND RAKE TRIM AT RIDGE FOR BEST RESULTS.

(WALL PANELS OMITTED FOR CLARITY)

**RAKE/PEAK INSTALLATION** 

RA07

LONG SPAN III ROOF W/DIE FORMED RIDGE

BA

Download the DWG file by clicking here.

To Section Index


Revised: 9/8/20

#### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Ridge Flashing Endcap Installation Standing Seam, Long Span III & Loc Seam Roofs RA14/AA




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Roof to Wall Flashing Endcap Installation Loc Seam, Long Span III & Standing Seam Roofs w/ Architectural III, Architectural "V" Rib & Long Span III Walls RA14A/AA




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Roof to Wall Transition Architectural III, Architectural "V" Rib or Long Span III Walls / Long Span III Roof Panels RA30/BB




Download the DWG file by clicking here.

### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Ridge Expansion Detail at Roof to Wall Transition Long Span III Roof RA32/BA




Download the DWG file by clicking here.

#### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Cleated Rake Detail Long Span III Roof / At Overhang or Canopy RA62A/BO




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Cleated Rake Detail Long Span III Roof / Architectural III, Architectural "V" Rib or Long Span III Wall Panels RA62/BB




Download the DWG file by clicking here.

### PRODUCT MANUAL

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Cleated Rake Detail Long Span III Roof w/ Shadow Panel Walls RA62/BD




Download the DWG file by clicking here.

#### **PRODUCT MANUAL**

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Cleated Rake Detail Long Span III Roof / At Open Wall RA62/BO




Download the DWG file by clicking here.

### PRODUCT MANUAL

LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Universal Rake Endcap Installation Left Hand Shown RA70/AA



Download the DWG file by clicking here.




LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Highside Eave Endcap, Without Corner Box

RA70A/AA




Download the DWG file by clicking here.



LONG SPAN III ROOF PANELS

A NUCOR COMPANY

Cleated Rake Endcap Installation All Roof Panels RA71/AA



Download the DWG file by clicking here.